



## Flow Calculations for the V-Cone<sup>®</sup> and Wafer-Cone<sup>®</sup> Flowmeters

### Basic flow equation:

English Units:

$$Q_{\text{acfs}} = \frac{\pi}{4} \sqrt{\frac{2g_c}{\rho}} \frac{D_{\text{ft}}^2 \beta^2}{\sqrt{1-\beta^4}} \sqrt{\Delta P_{\text{psf}}} \times C_f \times Y \quad \text{Volume flowrate}$$

$$Q_{\frac{\text{lb}}{\text{s}}} = \frac{\pi}{4} \sqrt{2g_c \times \rho} \frac{D_{\text{ft}}^2 \beta^2}{\sqrt{1-\beta^4}} \sqrt{\Delta P_{\text{psf}}} \times C_f \times Y \quad \text{Mass flowrate}$$

$$D_{\text{ft}} = \frac{D_{\text{in}}}{12} \quad \Delta P_{\text{psf}} = \Delta P_{\text{wc}} \times 5.197$$

$$Q_{\text{acfm}} = Q_{\text{acfs}} \times 60 \quad Q_{\text{acfh}} = Q_{\text{acfs}} \times 3600$$

$$Q_{\text{gpm}} = Q_{\text{acfm}} \times 7.4805 \quad Q_{\text{gph}} = Q_{\text{acfh}} \times 7.4805$$

Metric Units:

$$Q_{\frac{\text{m}^3}{\text{s}}} = \frac{\pi}{4} \sqrt{\frac{2}{\rho^*}} \frac{D_m^{*2} \beta^2}{\sqrt{1-\beta^4}} \sqrt{\Delta P_{\text{Pa}}^*} \times C_f \times Y \quad \text{Volume flowrate}$$

$$Q_{\frac{\text{kg}}{\text{s}}} = \frac{\pi}{4} \sqrt{2\rho^*} \frac{D_m^{*2} \beta^2}{\sqrt{1-\beta^4}} \sqrt{\Delta P_{\text{Pa}}^*} \times C_f \times Y \quad \text{Mass flowrate}$$

$$D_m^* = \frac{D_{\text{mm}}^*}{1000} \quad \Delta P_{\text{Pa}}^* = \Delta P_{\text{mbar}}^* \times 100$$

$$Q_{\frac{\text{m}^3}{\text{min}}} = Q_{\frac{\text{m}^3}{\text{s}}} \times 60 \quad Q_{\frac{\text{m}^3}{\text{h}}} = Q_{\frac{\text{m}^3}{\text{s}}} \times 3600$$

$$Q_{\frac{\text{L}}{\text{min}}} = \frac{Q_{\frac{\text{m}^3}{\text{min}}}}{1000} \quad Q_{\frac{\text{L}}{\text{h}}} = \frac{Q_{\frac{\text{m}^3}{\text{h}}}}{1000}$$

U.S. Patents 4638672, 4812049, 5363699, 4944190 and 5,814,738 European Patent 0277121 Canadian Patent 1325113

Japan Patent 1,858,116 Other U.S. & Foreign patents pending

McCrometer<sup>®</sup>, Inc., 3255 W. Stetson Ave., Hemet, CA 92545 PH 909-652-6811 FAX 909-652-3078 E-mail: [info@mccrometer.com](mailto:info@mccrometer.com)

Lit #24509-54 Rev. 3.0/10-02 ©2002 by McCrometer, Inc. Printed in USA

## **Gas Expansion Factor**

### **Precision tube V-Cone and Insertion Top-plate V-Cone Flowmeters (Rev. May 2001)**

#### **The equation for gas expansion for compressible fluid flow:**

NOTE: Y=1 for noncompressible fluids (e.g. water, oil etc.).

$$Y = 1 - (0.649 + 0.696\beta^4) \frac{\Delta P}{k \cdot P}$$

Note that  $\Delta P$  and  $P$  can be in any units as long as they are the same.

### **Wafer-Cone Flowmeters (Rev. Oct 2001)**

#### **The equation for gas expansion for compressible fluid flow:**

NOTE: Y=1 for non-compressible fluids (e.g. water, oil etc.).

$$Y = 1 - (0.755 + 6.787\beta^8) \frac{\Delta P}{k \cdot P}$$

### **The equation to convert from actual to standard / normal volume units:**

NOTE: This conversion is only used in compressible fluids.

English Units:

$$Q_{scfs} = Q_{acfs} \left( \frac{P_L}{P_b} \times \frac{T_b}{T} \times \frac{Z_b}{Z} \right)$$

Metric Units:

$$Q_{\frac{Nm^3}{s}} = Q_{\frac{m^3}{s}} \left( \frac{P_L^*}{P_b^*} \times \frac{T_b^*}{T^*} \times \frac{Z_b}{Z} \right)$$

### **The basic equation in terms of C:**

NOTE: C is used to simplify the flow equation by combining the constant and geometric variables.

English Units:

$$Q_{\text{acfs}} = C \times \sqrt{\frac{\Delta P_{\text{psf}}}{\rho}} \times Y \qquad C = 6.3002 \frac{D_{\text{ft}}^2 \beta^2}{\sqrt{1 - \beta^4}} C_d$$

Metric Units:

$$Q_{\frac{\text{m}^3}{\text{s}}} = C^* \times \sqrt{\frac{\Delta P_{\text{Pa}}^*}{\rho^*}} \times Y \qquad C^* = 1.1107 \frac{D_{\text{m}}^* \beta^2}{\sqrt{1 - \beta^4}} C_d$$

Note that calibrated meters have  $C_d$  expressed as a function of Reynolds Number. Therefore for the case of calibrated meters  $C$  or  $C^*$  will be expressed as functions of Reynolds Number.

### ***Linear velocity equations:***

English Units:

$$v = \frac{4Q_{\text{acfs}}}{\pi D_{\text{ft}}^2} \qquad v_{\text{throat}} = \frac{4Q_{\text{acfs}}}{\pi \beta^2 D_{\text{ft}}^2}$$

Metric Units:

$$v^* = \frac{4Q_{\frac{\text{m}^3}{\text{s}}}}{\pi D_{\text{m}}^{*2}} \qquad v_{\text{throat}}^* = \frac{4Q_{\frac{\text{m}^3}{\text{s}}}}{\pi \beta^2 D_{\text{m}}^{*2}}$$

### ***Beta ratio and cone diameter equations:***

English Units:

$$\beta = \sqrt{1 - \frac{d_{\text{in}}^2}{D_{\text{in}}^2}} \qquad d_{\text{in}} = D_{\text{in}} \sqrt{1 - \beta^2}$$

Metric Units:

$$\beta = \sqrt{1 - \frac{d_{\text{mm}}^{*2}}{D_{\text{mm}}^{*2}}} \qquad d_{\text{mm}}^* = D_{\text{mm}}^* \sqrt{1 - \beta^2}$$

**Beta Ratios:**

The standard beta ratios for V-Cone flowmeters are: 0.45, 0.55, 0.65, 0.75, and 0.8. Alternative beta ratios can be used if required. Note that differential pressure and/or gas expansion factor may limit the availability of even standard beta ratios. In a liquid application, beta ratios should not be used that cause static line pressure minus the differential pressure to be less than the fluid's vapor pressure. In vapor or gas applications, beta ratios should not be used that generate a gas expansion factor less than 0.84.

**Reynolds number equation:**

English Units:

$$Re = 123.9 \frac{v \times D_{in} \times \rho}{\mu}$$

Metric Units:

$$Re = \frac{D_{mm}^* \times v^* \times \rho^*}{\mu}$$

The V-Cone meters discharge coefficient is related to the flows Reynolds number. It is advised that the V-Cone meter be calibrated across the range of Reynolds numbers for which it is to be used. That is a plot of discharge coefficient to the Reynolds number should be produced and a line fit relating discharge coefficient to the Reynolds number should then be made.

**Flowing density equations:**

Liquids:  $\rho = Gr_f \times \rho_{water}$

Steam:  $\rho = \frac{1}{Sp.Vol.}$

Gas:  $\rho = 2.6988 \frac{S_g \times P_L}{Z \times T}$

Metric units:  $\rho^* = \rho \times 16.0184$

**Thermal expansion equation:**

When meters are subjected to substantially different temperatures than those at which they were calibrated, there can be an effect on meter performance due to the expansion of the cone and meter tube materials. Use this equation if the thermal expansion coefficients for the pipe and cone are equal:

$$F_a = 1 + 2\alpha(T - 528)$$

Use this set of equation if the coefficients are different:

U.S. Patents 4638672, 4812049, 5363699, 4944190 and 5,814,738 European Patent 0277121 Canadian Patent 1325113

Japan Patent 1,858,116 Other U.S. & Foreign patents pending

McCrometer®, Inc., 3255 W. Stetson Ave., Hemet, CA 92545 PH 909-652-6811 FAX 909-652-3078 E-mail: [info@mccrometer.com](mailto:info@mccrometer.com)

Lit #24509-54 Rev. 3.0/10-02 ©2002 by McCrometer, Inc. Printed in USA

$$F_a = \frac{D_{in}^2 - d_{in}^2}{((1 - \alpha_{pipe} \cdot (T - 528)) \cdot D_{in})^2 - ((1 - \alpha_{cone} \cdot (T - 528)) \cdot d_{in})^2}$$

To calculate the thermal expansion factor at operating temperature based on beta ratio:

$$\text{Calculate pipe diameter at operating temperature: } D'_{in} = D_{in} + (D_{in} \cdot \alpha_{pipe} \cdot (T' - T_c))$$

$$\text{Calculate cone diameter at operating temperature: } d'_{in} = d_{in} + (d_{in} \cdot \alpha_{cone} \cdot (T' - T_c))$$

$$\text{Calculate beta ratio at operating temperature: } \beta' = \sqrt{1 - \frac{d_{in}'^2}{D_{in}'^2}}$$

$$\text{Calculate thermal expansion factor at operating temperature: } F_a = \frac{\frac{D_{in}'^2 \cdot \beta'^2}{\sqrt{1 - \beta'^4}}}{\frac{D_{in}^2 \cdot \beta^2}{\sqrt{1 - \beta^4}}}$$

The example below demonstrates the use of this term:

$$Q_{acfs(at\_new\_temp)} = Q_{acfs} \times F_a$$

### ***Permanent pressure loss equation:***

Permanent pressure (or “total head”) loss in differential pressure meters is typically described as a percentage of the differential pressure created at a particular flowrate. An approximate V-Cone Meter permanent pressure loss can be found by applying the following equation:

$$\%P_{loss} = (1.3 - 1.25\beta) \times 100$$

## Nomenclature

$C$	meter constant
$C^*$	metric meter constant
$C_d$	discharge coefficient of the meter
$D_{ft}$	meter inside diameter in feet
$D_{in}$	meter inside diameter in inches
$D'_{in}$	pipe diameter at operating temperature in inches
$D^*_m$	meter inside diameter in meters
$D^*_{mm}$	meter inside diameter in millimeters
$d_{in}$	cone diameter in inches
$d'_{in}$	cone diameter at operating temperature in inches
$d^*_{mm}$	cone diameter in millimeters
$F_a$	meter thermal expansion factor
$g_c$	dimensional conversion constant, $32.174 \text{ lb}_m \text{ ft} / \text{lb}_f \text{ sec}^2$
$k$	fluid isentropic exponent at flowing conditions
$P$	absolute pressure in same units as $\Delta P$
$P_b$	base absolute pressure in psi ( <i>typically 14.696 psia</i> )
$P^*_b$	base absolute pressure in bars ( <i>typically 1.013 bara</i> )
$P_L$	absolute static line pressure in psi at the meter
$P^*_L$	absolute static line pressure in bars or psi at the meter
$Q_{acfs}$	volume flow rate in actual cubic feet per second
$Q_{acfm}$	volume flow rate in cubic feet per minute
$Q_{acfh}$	volume flow rate in cubic feet per hour
$Q_{gpm}$	volume flow rate in gallons per minute
$Q_{gph}$	volume flow rate in gallons per hour
$Q_{kg/s}$	mass flow rate in kilograms per second
$Q_{L/min}$	volume flow rate in liters per minute
$Q_{L/h}$	volume flow rate in liters per hour
$Q_{lb/s}$	mass flow rate in pounds mass per second
$Q_{m^3/min}$	volume flow rate in cubic meters per minute
$Q_{m^3/h}$	volume flow rate in cubic meters per hour
$Q_{m^3/s}$	volume flow rate in actual cubic meters per second
$Q_{Nm^3/h}$	volume flow rate in normal cubic meters per hour
$Q_{scfh}$	volume flow rate in standard cubic feet per hour
$Q_{scfm}$	volume flow rate in standard cubic feet per min
$R$	simplification term used in Y factor
$Re$	Reynolds number
$S_g$	specific gravity of the gas
$Sp. Vol.$	specific volume of the vapor
$T$	flowing temperature in degrees Rankine
$T^*$	flowing temperature in degrees Kelvin

$T_b$	base temperature in degrees Rankine ( <i>typically 520 R</i> )
$T_b^*$	base temperature in degrees Kelvin ( <i>typically 288.15 K</i> )
$T_c$	calibration temperature
$T'$	operating temperature
$v$	fluid velocity through the pipe, in feet per second
$v^*$	fluid velocity through the pipe, in meters per second
$v_{throat}$	fluid velocity at the throat, in feet per second
$v_{throat}^*$	fluid velocity at the throat, in meters per second
$Y$	adiabatic expansion factor for contoured elements note: $Y = 1$ for liquid flow applications
$Z$	flowing gas compressibility factor
$Z_b$	base gas compressibility factor
$\%P_{loss}$	permanent pressure loss across the meter as a percentage of differential pressure

### Greek symbols:

$\alpha_{PE}$	pipe and cone material coefficient of thermal expansion
$\alpha_{cone}$	thermal expansion coefficient of cone material
$\alpha_{pipe}$	thermal expansion coefficient of pipe material
$\beta$	meter beta ratio
$\beta'$	beta ratio at operating temperature
$\Delta P$	differential pressure in same units as $P$
$\Delta P_{Pa}^*$	differential pressure in Pascals
$\Delta P_{mbar}^*$	differential pressure in millibars
$\Delta P_{wc}$	differential pressure in inches of water column
$\mu$	operating fluid viscosity, in centipoise
$\pi$	3.14159
$\rho$	flowing fluid density in pounds mass per cubic foot
$\rho^*$	flowing fluid density in kilograms per cubic meter

## OTHER McCROMETER PRODUCTS INCLUDE:

**MC**<sup>®</sup> Propeller Liquid Flowmeters



**√CONE**<sup>®</sup> Differential Pressure Flowmeters

*Wafer-Cone*<sup>®</sup> Differential Pressure Flowmeters



Variable Area Meters

**ULTRA MAG**<sup>®</sup> Magnetic Flowmeters

Electronic Instrumentation for Remote Display and Control

FOR MORE INFORMATION CONTACT:

Represented by:



3255 W. Stetson Avenue, Hemet, CA 92545-7799

Phone: (909) 652-6811 Fax: (909) 652-3078

e-mail: [info@mccrometer.com](mailto:info@mccrometer.com) Web Site: <http://www.mccrometer.com>

Hours: 8 a.m. - 4:30 p.m. PST, Monday-Friday